

This figure shows a perspective view of a slot machine. The top section features a control panel with a digital display (110) showing the numbers 50, 200, 25, 375, and 100. Below the display is a coin slot (92) and a handle (84). To the right is a lever assembly (80, 88) with a handle (82). The middle section contains a reel assembly (86) with symbols (2x, 1, x8, 6x, 6). Below the reels is a payline indicator (90). The bottom section includes a coin return slot (34), a coin slot (30), and a coin counter (56). The base of the machine has a coin slot (22), a coin return slot (16), and a coin counter (20). The entire machine is supported by a base (24) with legs (26). External controls include a coin slot (18) on the right side and a handle (12) on the far right.

FIG.2




FIG.3




FIG.4




FIG. 5

